

**PRECAUTIONARY STATEMENTS  
HAZARDS TO HUMANS AND DOMESTIC ANIMALS**

**DANGER**

**KEEP OUT OF REACH OF CHILDREN**

Corrosive. Causes irreversible eye damage. Causes skin irritation. Harmful if inhaled. Harmful if swallowed. Harmful if absorbed through skin. Prolonged or frequently repeated skin contact may cause allergic reactions in some individuals. Causes asthmatic signs and symptoms in hyper-reactive individuals.

Do not get in eyes, on skin, on clothing. Avoid breathing vapor. Do not swallow. Wear goggles, protective clothing, and butyl or nitrile gloves. Wash thoroughly with soap and water after handling. Remove contaminated clothing and wash before reuse.

**ENVIRONMENTAL HAZARDS**

This pesticide is toxic to fish. Do not discharge effluent containing this product into lakes, streams, ponds, estuaries, oceans or other waters unless in accordance with the requirements of a National Pollutant Discharge Elimination System (NPDES) permit and the permitting authority has been notified in writing prior to discharge. Do not discharge effluent containing this product to sewer systems without previously notifying the local sewage treatment plant authority. For guidance, contact your State Water Board or Regional Office of the EPA.

**STORAGE AND HANDLING**

AQUCAR GA 15 Water Treatment Microbiocide is incompatible with many commonly used materials of construction such as steel, galvanized iron, aluminum, tin, and zinc. AQUCAR GA 15 Water Treatment Microbiocide can be stored and handled in baked phenolic-lined steel, polyethylene, stainless steel, or reinforced epoxy-plastic equipment. This product freezes at about 20.3° F (-6.5° C). Therefore, unless the storage tank is inside or underground, heating and insulation may be required. If heating is needed, exposure to high temperatures should be avoided. For short storage times (up to about 1 month), temperatures of up to 100° F (37.8° C) can be tolerated but the preferred maximum storage temperature is about 80° F (26.7° C).

A stainless steel centrifugal pump is suggested for transfer service. Spiral-wound stainless steel with TEFLON® Polymer is suitable for gaskets and packing.

Handle in a well-ventilated area. If vapors are irritating to the nose or eyes, special ventilation or respiratory protection (MSHA/NIOSH approved air purifying respirator equipped with an organic vapor cartridge) may be required.

**STORAGE AND DISPOSAL**

**PESTICIDE DISPOSAL:** Do not contaminate water, food or feed by storage or disposal. Open dumping is prohibited. Pesticide wastes are toxic. Improper disposal of excess pesticide, spray mixture or rinsate is a violation of Federal law. If these wastes cannot be disposed of by use according to label instructions, contact your State Pesticide or your Environmental Control Agency, or the Hazardous Waste representative at the nearest EPA Regional Office for guidance.

**CONTAINER DISPOSAL**  
Nonrefillable container. Do not reuse or refill this container. Triple or pressure rinse container (or equivalent) promptly after emptying. Then offer for recycling or reconditioning, or puncture and dispose of in a sanitary landfill, or other procedures approved by state and local authorities.

**BEFORE HANDLING OR USING THIS PRODUCT, SEE YOUR EMPLOYER AND READ CURRENT MATERIAL SAFETY DATA SHEET.**

# AQUCAR™ GA 15 Water Treatment Microbiocide

A highly effective Microbiocide for use in controlling Bacteria including Slime Forming Bacteria and Sulfate-Reducing Bacteria, Fungi (Yeast and Molds) and Algae in Air washers and Industrial Scrubbing Systems, Recirculating Cooling and Process Water Systems Including those that contain Reverse Osmosis Membranes and Service Water and Auxiliary Systems, Heat Transfer Systems, Wastewater Systems Including Wastewater Sludge and Holding Tanks, Paper Mills and Paper Mill Process Water Systems, Pigments and Filler Slurries for Paper and Paperboard, Water Based Coatings for Paper and Paperboard and in Oil Well Drilling, Oil Field Processing Applications, Oil Field Water Systems, Oil and Gas Production and Transmission Pipelines and Systems, and Gas Storage Fields and Equipment; such as Steam-Injection Water Holding Tanks, Flood Water, Fracturing Fluids, Injection Water, Holding Pond Water, Disposal-Well Water, Water Holding Tanks, Fuel Storage Tanks and related Refinery and Oil Field Closed, Industrial Recirculating Water Handling Systems.

<b>Active Ingredient:</b>		
	<b>Glutaraldehyde</b> .....	<b>15%</b>
<b>Inert Ingredient(s):</b> .....		<b>85%</b>
<b>Total</b> .....		<b>100%</b>

**KEEP OUT OF REACH OF CHILDREN  
DANGER**

<b>FIRST AID</b>	
<b>IF SWALLOWED:</b>	<ul style="list-style-type: none"> <li>• Call a poison control center or a doctor immediately for treatment advice.</li> <li>• DO NOT INDUCE VOMITING.</li> <li>• Do not give anything to drink.</li> </ul>
<b>IF IN EYES:</b>	<ul style="list-style-type: none"> <li>• Wash immediately and continuously with flowing water for at least 30 minutes.</li> <li>• Remove contact lenses after the first 5 minutes and continue washing. Obtain prompt medical consultation, preferably from an ophthalmologist.</li> <li>• Call a poison control center or a doctor immediately for treatment advice.</li> </ul>
<b>IF ON SKIN OR CLOTHING:</b>	<ul style="list-style-type: none"> <li>• Take off contaminated clothing.</li> <li>• Rinse skin immediately with plenty of water for 15–20 minutes.</li> <li>• Call a poison control center or a doctor for treatment advice.</li> </ul>
<b>IF INHALED:</b>	<ul style="list-style-type: none"> <li>• Move person to fresh air.</li> <li>• If person is not breathing, call 911 or an ambulance, and then give artificial respiration, preferably mouth-to-mouth if possible.</li> <li>• Call a poison control center or a doctor for further treatment advice.</li> </ul>
<b>NOTE TO PHYSICIAN:</b> Aspiration may cause lung damage. Probable mucosal damage may contraindicate the use of gastric lavage.	
Have the MSDS and, if available, the product container or label with you when calling a poison control center or a doctor, or going for treatment.	
<b>IN CASE OF AN EMERGENCY</b> endangering life or property involving this product, call collect (989)636-4400.	

**SEE SIDE PANEL FOR ADDITIONAL PRECAUTIONARY STATEMENTS.**

E.P.A. Registration No. 464-693  
E.P.A. Est. XXXXX-XXX

Produced for:



**The Dow Chemical Company**

Midland, Michigan 48674 U.S.A.

(989)636-4400

® TM Trademark of The Dow Chemical Company ("Dow") or an affiliated company of Dow

Made in U.S.A.

**NET CONTENTS: XXX gallons**  
**NET WEIGHT: XXX lb / XXX kg**  
**LOT NO:**

## DIRECTIONS FOR USE

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling.

**AIR WASHERS AND INDUSTRIAL SCRUBBING SYSTEMS/RECIRCULATING COOLING AND PROCESS WATER SYSTEMS**

This product may be used only in industrial air washers and air washer systems which have mist-eliminating components.

AQUCAR GA 15 Water Treatment Microbiocide should be added at the application rates described below to a water treatment system at a convenient point of uniform mixing such as the basin area. Addition may be made intermittently (SLUG DOSE) or continuously. Badly fouled systems can be shock treated with AQUCAR GA 15 Water Treatment Microbiocide. Under these conditions, blowdown should be discontinued for up to 24 hours.

AQUCAR GA 15 Water Treatment Microbiocide can be used in industrial process water systems that contain ultra filtration units and non-medical reverse osmosis membranes (where approved for compatibility by the membrane manufacturer) and associated distribution systems.

**INTERMITTENT (SLUG DOSE) METHOD**

**Initial Dose:** When the system is noticeably fouled, apply 4.1 to 8.2 fluid ounces of AQUCAR GA 15 Water Treatment Microbiocide per 100 gallons of water in the system. Repeat until control is achieved.

**Subsequent Dose:** When microbial control is evident, add 1.6 to 4.1 fluid ounces of AQUCAR GA 15 Water Treatment Microbiocide per 100 gallons of water in the system weekly, or as needed to maintain control.

Badly fouled systems must be cleaned before treatment is begun.

**CONTINUOUS FEED METHOD**

**Initial Dose:** When the system is noticeably fouled, apply 4.1 to 8.2 fluid ounces of AQUCAR GA 15 Water Treatment Microbiocide per 100 gallons of water in the system.

**Subsequent Dose:** Maintain this treatment level by starting a continuous feed of 0.8 to 4.1 fluid ounces of AQUCAR GA 15 Water Treatment Microbiocide per 100 gallons of water in the system per day.

Badly fouled systems must be cleaned before treatment is begun.

**SERVICE WATER AND AUXILIARY SYSTEMS**

AQUCAR GA 15 Water Treatment Microbiocide should be used at the same application rates, and in the same manner as described above. It should be added to the system at a point that will allow for uniform mixing throughout the system.

**HEAT TRANSFER SYSTEMS**

(Evaporative Condensers, Dairy Sweetwater Systems, Hydrostatic Sterilizers And Retorts, And Pasteurizers And Warmers)

AQUCAR GA 15 Water Treatment Microbiocide should be used at the same application rates, and in the same manner as described above. It should be added to the system at a point of uniform mixing such as a basin area, sump area, or other reservoir or collecting area from which the treated water will be circulated uniformly throughout the system.

**INDUSTRIAL WASTEWATER SYSTEMS**

(Wastewater Systems, Wastewater Sludge And Wastewater Holding Tanks)

AQUCAR GA 15 Water Treatment Microbiocide should be added to a wastewater system or sludge at a convenient point of uniform mixing such as the digester. Add 1.4 to 7.2 gallons (1500 to 7,500 ppm AQUCAR GA 15 Water Treatment Microbiocide) per 1,000 gallons of wastewater or sludge.

**PAPER MILLS AND PAPER MILL PROCESS WATER SYSTEMS**

AQUCAR GA 15 Water Treatment Microbiocide should be added to the paper making system at a point of uniform mixing such as the beaters, broke chest pump, save-all tank, or white-water tank.

**Initial Dose:** When the system is noticeably contaminated, add 1.7 to 9.9 lbs of AQUCAR GA 15 Water Treatment Microbiocide per ton of pulp or paper (dry basis) as a slug dose. Repeat until control is achieved. Heavily fouled systems should be boiled out prior to initial treatment.

**Subsequent Dose:** When microbial control is evident, add 1.0 to 6.6 lbs of AQUCAR GA 15 Water Treatment Microbiocide per ton of pulp or paper (dry basis) as a slug dose as necessary to maintain control.

**PIGMENTS AND FILLER SLURRIES FOR PAPER AND PAPERBOARD**

(For use in food and non-food contact pigments and filler slurries)

Use from 0.33 to 2.0 lbs. of AQUCAR GA 15 Water Treatment Microbiocide per 1,000 lbs. of dry powder to produce a concentration from 333 to 2,000 ppm as product (based on slurry solids) in the mixed slurry.

**WATER BASED COATINGS FOR PAPER AND PAPERBOARD**

**NOTE:** For use in non-food contact coatings only.

Use from 0.33 to 2.0 lbs. of AQUCAR GA 15 Water Treatment Microbiocide per 1,000 lbs. of dry powder to produce a concentration from 333 to 2,000 ppm as product (based on slurry solids) in the mixed slurry.

**WATER FLOODS**

AQUCAR GA 15 Water Treatment Microbiocide should be added to a water flood system at a point of uniform mixing.

**Initial Treatment:** When the system is noticeably contaminated, add 330 to 16,670 ppm AQUCAR GA 15 Water Treatment Microbiocide to the system (0.3 to 16.0 gallons AQUCAR GA 15 Water Treatment Microbiocide per 1,000 gallons flood water). Repeat until control is achieved.

**Subsequent Dose:** When microbial control is evident, add 67 to 16,670 ppm AQUCAR GA 15 Water Treatment Microbiocide (0.06 to 16.0 gallons AQUCAR GA 15 Water Treatment Microbiocide per 1,000 gallons flood water) to the system weekly, or as needed to maintain control.

**FRAC FLUIDS**

**Product not registered for this use in the State of California.**

AQUCAR GA 15 Water Treatment Microbiocide reduces bacterial contamination and degradation of fracturing fluids and gels used in oil and gas well stimulations. Add AQUCAR GA 15 Water Treatment Microbiocide to the frac water storage tanks or directly into the well head injection pipeline as the water is being pumped down-hole.

Dose Range: AQUCAR GA 15 Water Treatment Microbiocide should be added at a rate of 333 to 16,667 (3.2 – 160 gallons per 10,000 gallons) depending on the degree of bacterial fouling in the source water.

**DRILLING, COMPLETION, AND WORKOVER FLUIDS**

AQUCAR GA 15 Water Treatment Microbiocide should be added to a drilling fluid system at a point of uniform mixing such as the circulating mud tank.

**Initial treatment:** Add 170 to 3,330 ppm AQUCAR GA 15 Water Treatment Microbiocide (0.7 to 13.4 gallons AQUCAR GA 15 Water Treatment Microbiocide per 100 barrels of fluid) to a freshly prepared fluid depending on the severity of contamination.

**Maintenance dosage:** Maintain a concentration of 170 to 3,330 ppm AQUCAR GA 15 Water Treatment Microbiocide by adding 0.7 to 13.4 gallons of AQUCAR GA 15 Water Treatment Microbiocide per 100 barrels of additional fluid, or as needed, depending on the severity of contamination.

**PACKER FLUIDS**

AQUCAR GA 15 Water Treatment Microbiocide should be added to a packer fluid at a point of uniform mixing such as a circulating holding tank. Add 170 to 2,000 ppm AQUCAR GA 15 Water Treatment Microbiocide (0.7 to 8.1 gallons AQUCAR GA 15 Water Treatment Microbiocide per 100 barrels of fluid) to a freshly prepared fluid depending on the severity of contamination. Seal the treated packer fluid in the wall between the casing and production tube.

**OIL PRODUCTION AND TRANSMISSION PIPELINES AND SYSTEMS**

**Product not registered for this use in the State of California.**

AQUCAR GA 15 Water Treatment Microbiocide should be added to an oil production or transmission line via direct injection. The application should be conducted to ensure maximum distribution of AQUCAR GA 15 Water Treatment Microbiocide throughout the entire internal pipeline surface by adding a sufficient amount of biocide to detect/measure a residual concentration at the back end of the pipeline system. Criteria for success of the treatment will be a reduction in bacterial counts and/or reduced corrosion rates. To facilitate application, it may be desirable to dilute the AQUCAR GA 15 Water Treatment Microbiocide with an appropriate solvent immediately before use. The concentration in the solvent should not fall below an active concentration range of 500 to 5,000 ppm based on the volume of water in the pipeline. Injections to the system should be weekly, or as needed to maintain control.

**GAS PRODUCTION AND TRANSMISSION PIPELINES AND SYSTEMS**

AQUCAR GA 15 Water Treatment Microbiocide should be added to a gas production or transmission pipeline via direct injection. The application should be conducted to ensure maximum distribution of AQUCAR GA 15 Water Treatment Microbiocide throughout the entire internal pipeline surface by adding a sufficient amount of biocide to detect/measure a residual concentration at the back end of the pipeline system. Criteria for success of the treatment will be a reduction in bacterial counts and/or reduced corrosion rates. To facilitate application, it may be desirable to dilute the AQUCAR GA 15 Water Treatment Microbiocide with an appropriate solvent immediately before use. The concentration in the solvent should not fall below an active concentration range of 500 to 5,000 ppm based on the volume of water in the pipeline. Injections to the system should be weekly, or as needed to maintain control.

**GAS STORAGE WELLS AND SYSTEMS**

Individual injection wells should be treated with a sufficient quantity of AQUCAR GA 15 Water Treatment Microbiocide to produce a concentration of 1,670 to 16,670 ppm AQUCAR GA 15 Water Treatment Microbiocide when diluted by the water present in the formation. Injection should take place before gas is injected (during the summer). Injections should be repeated yearly, or as needed to maintain control.

Individual drips should be treated with a sufficient quantity of AQUCAR GA 15 Water Treatment Microbiocide to produce a concentration of 670 to 6,670 ppm AQUCAR GA 15 Water Treatment Microbiocide when diluted by the water present in the drip. Injections should be repeated yearly, or as needed to maintain control.

**HYDROTESTING**

Water used to hydrotest pipelines or vessels should contain 330 to 13,330 ppm AQUCAR GA 15 Water Treatment Microbiocide (0.3 to 12.8 gallons AQUCAR GA 15 Water Treatment Microbiocide per 1,000 gallons water), depending on water quality and length of time the equipment will remain idle.

**PIPELINE PIGGING AND SCRAPING OPERATIONS**

Add AQUCAR GA 15 Water Treatment Microbiocide to a slug of water immediately following the scraper (ideally this water volume can be kept to a minimum and contained between the scraper and a trailing pig). Sufficient AQUCAR GA 15 Water Treatment Microbiocide should be added to produce a concentration of 0.3 to 3.3% (0.3 to 3.2 gallons AQUCAR GA 15 Water Treatment Microbiocide per 100 gallons water), depending on the length of the pipeline and the severity of biofouling.

Water used to hydrotest pipelines or vessels should contain 330 to 13,330 ppm AQUCAR GA 15 Water Treatment Microbiocide (0.3 to 12.8 gallons AQUCAR GA 15 Water Treatment Microbiocide per 1,000 gallons water), depending on water quality and length of time the equipment will remain idle.

**PIPELINE PIGGING AND SCRAPING OPERATIONS**  
Add AQUCAR GA 15 Water Treatment Microbiocide to a slug of water immediately following the scraper (ideally this water volume can be kept to a minimum and contained between the scraper and a trailing pig). Sufficient AQUCAR GA 15 Water Treatment Microbiocide should be added to produce a concentration of 0.3 to 3.3% (0.3 to 3.2 gallons AQUCAR GA 15 Water Treatment Microbiocide per 100 gallons water), depending on the length of the pipeline and the severity of biofouling.

**HYDROTESTING**

Water used to hydrotest pipelines or vessels should contain 330 to 13,330 ppm AQUCAR GA 15 Water Treatment Microbiocide (0.3 to 12.8 gallons AQUCAR GA 15 Water Treatment Microbiocide per 1,000 gallons water), depending on water quality and length of time the equipment will remain idle.

**PIPELINE PIGGING AND SCRAPING OPERATIONS**

Add AQUCAR GA 15 Water Treatment Microbiocide to a slug of water immediately following the scraper (ideally this water volume can be kept to a minimum and contained between the scraper and a trailing pig). Sufficient AQUCAR GA 15 Water Treatment Microbiocide should be added to produce a concentration of 0.3 to 3.3% (0.3 to 3.2 gallons AQUCAR GA 15 Water Treatment Microbiocide per 100 gallons water), depending on the length of the pipeline and the severity of biofouling.

Water used to hydrotest pipelines or vessels should contain 330 to 13,330 ppm AQUCAR GA 15 Water Treatment Microbiocide (0.3 to 12.8 gallons AQUCAR GA 15 Water Treatment Microbiocide per 1,000 gallons water), depending on water quality and length of time the equipment will remain idle.

**PIPELINE PIGGING AND SCRAPING OPERATIONS**  
Add AQUCAR GA 15 Water Treatment Microbiocide to a slug of water immediately following the scraper (ideally this water volume can be kept to a minimum and contained between the scraper and a trailing pig). Sufficient AQUCAR GA 15 Water Treatment Microbiocide should be added to produce a concentration of 0.3 to 3.3% (0.3 to 3.2 gallons AQUCAR GA 15 Water Treatment Microbiocide per 100 gallons water), depending on the length of the pipeline and the severity of biofouling.

Water used to hydrotest pipelines or vessels should contain 330 to 13,330 ppm AQUCAR GA 15 Water Treatment Microbiocide (0.3 to 12.8 gallons AQUCAR GA 15 Water Treatment Microbiocide per 1,000 gallons water), depending on water quality and length of time the equipment will remain idle.

**PIPELINE PIGGING AND SCRAPING OPERATIONS**  
Add AQUCAR GA 15 Water Treatment Microbiocide to a slug of water immediately following the scraper (ideally this water volume can be kept to a minimum and contained between the scraper and a trailing pig). Sufficient AQUCAR GA 15 Water Treatment Microbiocide should be added to produce a concentration of 0.3 to 3.3% (0.3 to 3.2 gallons AQUCAR GA 15 Water Treatment Microbiocide per 100 gallons water), depending on the length of the pipeline and the severity of biofouling.

Water used to hydrotest pipelines or vessels should contain 330 to 13,330 ppm AQUCAR GA 15 Water Treatment Microbiocide (0.3 to 12.8 gallons AQUCAR GA 15 Water Treatment Microbiocide per 1,000 gallons water), depending on water quality and length of time the equipment will remain idle.

**PIPELINE PIGGING AND SCRAPING OPERATIONS**  
Add AQUCAR GA 15 Water Treatment Microbiocide to a slug of water immediately following the scraper (ideally this water volume can be kept to a minimum and contained between the scraper and a trailing pig). Sufficient AQUCAR GA 15 Water Treatment Microbiocide should be added to produce a concentration of 0.3 to 3.3% (0.3 to 3.2 gallons AQUCAR GA 15 Water Treatment Microbiocide per 100 gallons water), depending on the length of the pipeline and the severity of biofouling.

Water used to hydrotest pipelines or vessels should contain 330 to 13,330 ppm AQUCAR GA 15 Water Treatment Microbiocide (0.3 to 12.8 gallons AQUCAR GA 15 Water Treatment Microbiocide per 1,000 gallons water), depending on water quality and length of time the equipment will remain idle.

**PIPELINE PIGGING AND SCRAPING OPERATIONS**  
Add AQUCAR GA 15 Water Treatment Microbiocide to a slug of water immediately following the scraper (ideally this water volume can be kept to a minimum and contained between the scraper and a trailing pig). Sufficient AQUCAR GA 15 Water Treatment Microbiocide should be added to produce a concentration of 0.3 to 3.3% (0.3 to 3.2 gallons AQUCAR GA 15 Water Treatment Microbiocide per 100 gallons water), depending on the length of the pipeline and the severity of biofouling.

Water used to hydrotest pipelines or vessels should contain 330 to 13,330 ppm AQUCAR GA 15 Water Treatment Microbiocide (0.3 to 12.8 gallons AQUCAR GA 15 Water Treatment Microbiocide per 1,000 gallons water), depending on water quality and length of time the equipment will remain idle.

**PIPELINE PIGGING AND SCRAPING OPERATIONS**  
Add AQUCAR GA 15 Water Treatment Microbiocide to a slug of water immediately following the scraper (ideally this water volume can be kept to a minimum and contained between the scraper and a trailing pig). Sufficient AQUCAR GA 15 Water Treatment Microbiocide should be added to produce a concentration of 0.3 to 3.3% (0.3 to 3.2 gallons AQUCAR GA 15 Water Treatment Microbiocide per 100 gallons water), depending on the length of the pipeline and the severity of biofouling.

Water used to hydrotest pipelines or vessels should contain 330 to 13,330 ppm AQUCAR GA 15 Water Treatment Microbiocide (0.3 to 12.8 gallons AQUCAR GA 15 Water Treatment Microbiocide per 1,000 gallons water), depending on water quality and length of time the equipment will remain idle.

**PIPELINE PIGGING AND SCRAPING OPERATIONS**  
Add AQUCAR GA 15 Water Treatment Microbiocide to a slug of water immediately following the scraper (ideally this water volume can be kept to a minimum and contained between the scraper and a trailing pig). Sufficient AQUCAR GA 15 Water Treatment Microbiocide should be added to produce a concentration of 0.3 to 3.3% (0.3 to 3.2 gallons AQUCAR GA 15 Water Treatment Microbiocide per 100 gallons water), depending on the length of the pipeline and the severity of biofouling.

Water used to hydrotest pipelines or vessels should contain 330 to 13,330 ppm AQUCAR GA 15 Water Treatment Microbiocide (0.3 to 12.8 gallons AQUCAR GA 15 Water Treatment Microbiocide per 1,000 gallons water), depending on water quality and length of time the equipment will remain idle.

**PIPELINE PIGGING AND SCRAPING OPERATIONS**  
Add AQUCAR GA 15 Water Treatment Microbiocide to a slug of water immediately following the scraper (ideally this water volume can be kept to a minimum and contained between the scraper and a trailing pig). Sufficient AQUCAR GA 15 Water Treatment Microbiocide should be added to produce a concentration of 0.3 to 3.3% (0.3 to 3.2 gallons AQUCAR GA 15 Water Treatment Microbiocide per 100 gallons water), depending on the length of the pipeline and the severity of biofouling.

Water used to hydrotest pipelines or vessels should contain 330 to 13,330 ppm AQUCAR GA 15 Water Treatment Microbiocide (0.3 to 12.8 gallons AQUCAR GA 15 Water Treatment Microbiocide per 1,000 gallons water), depending on water quality and length of time the equipment will remain idle.

**PIPELINE PIGGING AND SCRAPING OPERATIONS**  
Add AQUCAR GA 15 Water Treatment Microbiocide to a slug of water immediately following the scraper (ideally this water volume can be kept to a minimum and contained between the scraper and a trailing pig). Sufficient AQUCAR GA 15 Water Treatment Microbiocide should be added to produce a concentration of 0.3 to 3.3% (0.3 to 3.2 gallons AQUCAR GA 15 Water Treatment Microbiocide per 100 gallons water), depending on the length of the pipeline and the severity of biofouling.

Water used to hydrotest pipelines or vessels should contain 330 to 13,330 ppm AQUCAR GA 15 Water Treatment Microbiocide (0.3 to 12.8 gallons AQUCAR GA 15 Water Treatment Microbiocide per 1,000 gallons water), depending on water quality and length of time the equipment will remain idle.

**PIPELINE PIGGING AND SCRAPING OPERATIONS**  
Add AQUCAR GA 15 Water Treatment Microbiocide to a slug of water immediately following the scraper (ideally this water volume can be kept to a minimum and contained between the scraper and a trailing pig). Sufficient AQUCAR GA 15 Water Treatment Microbiocide should be added to produce a concentration of 0.3 to 3.3% (0.3 to 3.2 gallons AQUCAR GA 15 Water Treatment Microbiocide per 100 gallons water), depending on the length of the pipeline and the severity of biofouling.



**NOTICE**

Do Not Ship or Store with Food, Feeds, Drugs, or Clothing